

# FABRIC FLAG INSTRUCTIONS

## KIT CONTAINS:

1 FABRIC FLAG  
1 WATER BAG

SEGMENTED POLE SET ( SPLIT INTO 4 PARTS )  
1 CROSS BASE

1 GROUND SPIKE  
INSTRUCTIONS

STRING


## ASSEMBLY




Lay out the pole set.  
NOTE: Flexible plastic pole goes on the top.



Assemble the poles.



Begin to gently put the flag onto the assembled pole.




Pull the flag entirely down onto the pole. Secure it onto the hook on the bottom pole with string.

NOTE:  
The flag hardware may include a different hook, pictured above.

## BASE OPTIONS PROVIDED

### GROUND STAKE

This 25" long metal spike is great for installing flags outdoors in solid soil and typically provides the greatest stability for outdoor use.



18.5" MAX IN-GROUND DEPTH



### CROSS BASE

This base has 4 legs and a foldable design making it a great option for indoor use, and flags that may require travel. If use indoors with higher amounts of foot traffic, be careful to place it so that it does not create a tripping hazard.



### WATER BAG

To more securely anchor your flag, use a refillable water bag to put over the top of your cross base. This heavy plastic ring full of water adds 16 pounds of weight to secure your flag.

